



User Manual

Dear Buyer,

Thanks for your purchase our BOYI 61Mini Bluetooth Wireless& Wired Multi-device Mechanical Keyboard! Our BOYI 61 Mini Keyboard will have 1 Year Warranty Service except for human damage factors. It is our pleasure to do business with you.

The BOYI keyboard has been sent with care. We hope you are satisfied with it and our service, and leave us positive feedback with 5-star DSRs in all categories. Which is a huge motivation for us to be a better keyboard seller.

We are honest keyboard seller and do our best to serve you. So if you have any issues or concerns, please don't hesitate to contact us by e-mail:(Boyiservice2020@163.com) for solution and we will do our best to help you. Look forward to serving you again in the near future!

Best regards,
BOYI Keyboard Serive

<https://www.amazon.com/boyi>

COMBINATION KEYS

FN+1=F1 FN+2=F2 FN+3=F3 FN+4=F4 FN+5=F5 FN+6=F6
 FN+7=F7 FN+8=F8 FN+9=F9 FN+0=F10 FN+_=F11 FN+`=F12
 FN+ESC= ` ~ L_Win+ R_Win = Reset

FN+Q=Media Player FN+W=Volume Down
 FN+E=Volume Up FN+R=Mute
 FN+A=Stop FN+S=Previous Track
 FN+D=Play/Pause FN+F=Next Track

FN+Y=Prtsc FN+U=Scrlk
 FN+I=Pause FN+O=INS
 FN+H=HOME FN+[=[PGUP
 FN+]=DEL FN+;=END
 FN+~=PGDOWN FN+TAB=MagicFN1

FN+/=Arrow key switch
 When switching the direction keys, the four keys in the figure below are cut into up, down, left, and right keys to light up white at the same time. Normally, the light follows the backlight.

Fn+R_ALT+L	Decrease LED Speed
Fn+R_ALT+J	Increase LED Speed
Fn+R_ALT+X	Decrease Brightness
Fn+R_ALT+C	Increase Brightness
Fn+R_ALT+T	Switch to different light modes
Fn+R_ALT+P	Turn on/off (background) light
Fn+R_ALT+V	Switch to different light color
Fn+R_ALT+B	Switch to light direcion

LIST OF LIGHT MODES

Light wave	●	Polymerization	●
Normal	●	Neon lights	●
Breath	●	Sine wave	●
Ripple	●	Light flowers	●
Light rain	●	Colorful spring surging	●
Serpentine	●	Meteor Chase	●
Follow	●		