



Combination	Function
FN+ESC	~
FN+1	F1
FN+2	F2
FN+3	F3
FN+4	F4
FN+5	F5
FN+6	F6
FN+7	F7
FN+8	F8
FN+9	F9
FN+0	F10
FN+-	F11
FN+=	F12
FN+U	PRT SCR
FN+I	Scrlk
FN+P	Switch to different light color
FN+[	Decrease Brightness
FN+]	Increase Brightness
FN+\	Switch to different light mode
FN+A	Pause/Play
FN+S	Previous song

#### FN+D Next song FN+F Mute FN+G Volume up FN+H Volume down FN+I INS FN+K HOME FN+; Decrease LED speed FN+' Increase LED speed FN+Pause 2.4G wireless mode connection FN+Pg Up Turn on/off all backlight FN+Pg dn Switch to custom backlight mode FN+Z Bluetooth device 1 FN+X Bluetooth device 2 FN+C Bluetooth device 3 FN+, END FN+Win Lock the WIN

Reset to factory defaults

Ctrl+Alt+Q

Lithium battery(3.7V):If the battery voltage is lower than 3.3V, the red indicator light of the keyboard will flash. The red indicator light is on when charging and off when fully charged.

## 1.1.2 2.4G wireless mode connection:

After the keyboard is turned on,long press "FN+Pause" combination keys 3 seconds and the indicator light will flash quickly. If the indicator keeps on for 10 seconds after plugging in the receiver.kevboard is connected in this mode.

### 1.1.3 Bluetooth mode connection:

Long press "FN+Z/X/C" combination keys 3 seconds,the indicator will flash quickly.If the indicator keeps on for 10 seconds after connecting your device, the keyboard is connected in this mode.If the keyboard isn't connected,the indicator goes out and the keyboard will go into the

### 1.1.4 Backlit modes:

Press "FN+\" combination keys to switch the keyboard backlit modes. Backlit mode:light wave(default),normal,breath,ripple,light

rain, serpentine, follow, polymerization, neon, laser, sine wave, RGB wave, aurora wave, light flowers, colorful spring surging.

The function of "FN+PgUp" combination keys is turn on/off all backlit.And press "FN+Pg dn" combination keys to switch to the custom backlit mode. The default backlit mode is inverted triangle lighting effect. Adjusting the custom backlit needs to use the keyboard drive.

The normal backlit mode can't adjust the light speed, neon and RGB wave backlit mode can't adjust the light color. Other backlit modes can adjust different light speed, brightness and color.There are 7 levels of the brightness and its default is maximum brightness.There are 5 levels of the speed and its default is the third level.Color order:multicolor,iceblue,red,green,blue, orange,purple,yellow.

# 1.1.5 Keyboard display name:

Wired mode:Thunderobot KC3068 2.4G mode:TR KC3068 2.4G BT3.0 mode:TR KC3068 BT3.0 BT5.0 mode:TR KC3068

1.1.6 Operating distance: >10m 360° (under external environment interference)

1.1.7 Bluetooth connection back time:≤5s

Bluetooth:Compatible with all Bluetooth Dongle on the market,notebook built-in Bluetooth module.Bluetooth 5.0 mode needs to support Windows 8 or above,tablets and mobile 2.4G:According to USB standard protocol,compatible with Windows2000 and MAC.

# 1.1.9 Electrical specifications (for reference only)

111.5 Electrical specifications (for reference only)	
540-580mA	
110.2mA	
200.0mA	
0.14mA	
183.5mA	
0.14mA	
182.6mA	
0.14mA	
39.8mA	

1.1.10 NKRO: all the connection mode and connected devices support anti-ghosting. 1.1.11 Working voltage:3.7V

1.1.12 Connection mode:wired, 2.4G, Bluetooth 3.0, Bluetooth 5.0

1.1.13 Compatible system Windows2000 or above,MAC,BLE support Windows 8 or above

