

GMK67 Aluminum Alloy Kit

Tri-mode wireless gasket gaming keyboard hot swappable, function knob

Quick Start Guide

Keyboard Features:

Keys:67keys

Battery:1000mA

Current:160mA

Voltage:Dc 5V

Keyboard size:325*114*31mm ±2mm

GMK67 Aluminum Alloy CNC Kit Driver download website:

https://www.boyikeyboard.com/Download.htm

BOYI Customer Service E-mail address:

boyiservice2020@163.com

BOYI Official Website:

www.boyikeyboard.com

Keyboard Layout:



Product parameter

Kit size (without key caps)	325.6*114*31 ±2mm
Number of keys	66 keys+knob
Connect Mode	BT/2.4G wireless/TYPE-C wired
Backlight color	RGB light
Shaft body	Mechanical shaft body
Featured features	full key hot swappable, support three pin/five pin shaft body
WARRANTY	Warranty for 12 months (except for man- made damage)



Packing list Keyboard *1, USB-TYPE-C data cable *1, dual spindle/key cap tool*1,user manual*1 ,2.4G receiver * 1

System requirements

Bluetooth mode: Computers, phones, tablets, and other devices with Bluetooth 4.0, Bluetooth 5.0, or higher Bluetooth functionality.

Wired/2.4G mode: Desktop computers, laptops, and other devices with available USB interfaces.

Tutorial for using(Bluetooth5.0/2.4G/Type-C Tri-Mode)

Wired mode:




When using wired mode, push the switch to the right, FN+TAB key to switch to wired mode, data Connect


thekeyboard and computer with a cable to use.
Wired connection will charge the the third mock examination keyboard battery at the same time

When the battery is low, the battery indicator lights red and flashes a prompt

Charging voltage/current: DCSV == 1A (MAX), It is recommended to connect the computer USB port for charging. Using high-power fast charging can easily damage the keyboard

This keyboard does not have waterproof function and may cause keyboard malfunction after liquid injection





2.4G wireless mode:



When using 2.4G wireless, push the switch to the right, use the FN+R key to switch to the 2.4G channel, use the R key to flash, and insert the receiver into the computer USB port, R key light stops flashing, you can us the keyboard wirelessly.

(Press and hold Fn+R for about 3 seconds. After the R key flashes quickly, plug the receiver into the computer's USB port to re pair.)

Bluetooth mode:



When using Bluetooth, push the switch to the right and short press Fn+Q to switch Blueto channel, Bluetooth pairing: Long press FN+Q, wait for the Q key to indicate After the light flashes quickly, search for pairing with Bluetooth ccessfully Use. (W/E key operation as above)



FN composite key

H-Left CTRL Switch Number Key Default Function hen synchronizing backight with the left CTRL key, the number keys default to 1-+functions hen the left CTRL key lights up with white light, the number keys default to F1-F12 functions, and the FN in the CTRL key lights up with white light, the number keys default to F1-F12 functions, and the FN in the CTRL key light up with white light.

Fn+	F1	F2	F3	F4	F	-5	F6		F	7	F8	3 F9	F10	F11	F12
WIN	My Computer	Home page	Mail	Calculator	PL	ayer	Sti	op Prev			Play / Paus	rope		2 Volume	Volume+
MAG	Brightness	Brightness +							Previ sor		Play / Paus	rope		2 Volume	Volume+
Fn+	ESC	WIN	А	S	1		. :		}		t	4	+	+	spacebar
FC	Factory reset	Lock WIN key	's WIN	I MA	.C	Light effect switching			Color switching		klight ntness+	Backlight Brightness-		Backlight Speed +	Backlight On/Off

Knob operation: Press and hold for about 5 seconds to switch between volume control/light effect control functions Volume mode: Short press the knob to turn mute on/off, rotate clockwise to increase volume, and counterclockwise to decrease volume Light effect mode: Short press to switch backlight light effect, rotate clockwise to increase backlight brightness, and counterclockwise to decrease backlight brightness