

Combination Function FN+ESC FN++Shift+ESC FN+1 FN+2 FN+3 FN+4 F4 FN+5 FN+6 FN+7 FN+8 FN+9 FN+0 F10 FN+-F11 FN+= FN+U PRT SCR FN+I Scroll Switch to different light color FN+P FN+[Decrease light Brightness FN+] Increase light Brightness FN+\ Switch to different light mode FN+A Pause/Play

Previous song

FN+S

FN+D	Next song
FN+F	Mute
FN+G	Volume up
FN+H	Volume down
FN+J	INS
FN+K	HOME
FN+;	Decrease LED light speed
FN+'	Increase LED light speed
FN+Pause	2.4G wireless mode connection
FN+Pg Up	Turn on/off all backlight
FN+Pg dn	Switch to custom backlight mode
FN+Z	Bluetooth device 1
FN+X	Bluetooth device 2
FN+C	Bluetooth device 3
FN+,	END
FN+Win	Lock the WIN
Ctrl+Alt+Q	Reset to factory defaults

BOYI WK68 Software Driver-Remap Your WK68 keyboard

Step 2:Download the File:BOYI WK68 Software Drive

Step 1:Please Visit: https://www.boyikeyboard.com/Download.html

1.1.1 Power Indicator Light:

Lithium battery(3.7V):If the battery voltage is lower than 3.3V, the red indicator light of the keyboard will flash. The red indicator light is on when charging and off when fully charged.

1.1.2 2.4G wireless mode connection:

After the keyboard is turned on,long press "FN+Pause" combination keys 3 seconds and the indicator light will flash quickly.If the indicator keeps on for 10 seconds after plugging in the receiver, keyboard is connected in this mode.

1.1.3 Bluetooth mode connection:

Long press "FN+Z/X/C" combination keys 3 seconds, the indicator will flash quickly. If the indicator keeps on for 10 seconds after connecting your device, the keyboard is connected in this mode.If the keyboard isn't connected,the indicator goes out and the keyboard will go into the sleep mode.

1.1.4 Backlit modes:

Press "FN+\" combination keys to switch the keyboard backlit modes.

Backlit mode: light wave(default),normal,breath,ripple,light rain,serpentine,follow, polymerization, neon, laser, sine wave, RGB wave, aurora wave, light flowers, colorful spring surging.

The function of "FN+PgUp" combination keys is turn on/off all backlit.And press "FN+Pg dn" combination keys to switch to the custom backlit mode. The default backlit mode is inverted triangle lighting effect. Adjusting the custom backlit needs to use the keyboard drive.

The normal backlit mode can't adjust the light speed, neon and RGB wave backlit mode can't adjust the light color.Other backlit modes can adjust different light speed, brightness and color. There are 7 levels of the brightness and its default is maximum brightness. There are 5 levels of the speed and its default is the third level.Color order:multicolor,iceblue,red,green,blue, orange,purple,yellow.

1.1.5 Keyboard display name:

Product Model:BOYI WK68

Wired after connection:BOYI 68 Mini

2.4G after connection: 2.4G Wireless Device

BT3.0 after connection: BT3.0 KB

BT5.0 after connection: BT5.0 KB

1.1.6 Operating distance: >10m 360° (under external environment interference)

1.1.7 Bluetooth connection back time:≤5s

1.1.8 Compatibility:

Bluetooth:Compatible with all Bluetooth Dongle on the market,notebook built-in Bluetooth module.Bluetooth 5.0 mode needs to support. Windows 8 or above,tablets and mobile

2.4G:According to USB standard protocol,compatible with Windows2000 and MAC.

1.1.9 Electrical specifications (for reference only)

Charging current	540-580mA
Wired normal mode current	110.2mA
2.4G normal mode current	200.0mA
2.4G sleep mode current	0.14mA
Bluetooth 3.0 normal mode current	183.5mA
Bluetooth 3.0 sleep mode current	0.14mA
Bluetooth 5.0 normal mode current	182.6mA
Bluetooth 5.0 sleep mode current	0.14mA
No backlit current	39.8mA

1.1.10 NKRO: all the connection mode and connected devices support anti-ghosting. 1.1.11 Working voltage:3.7V

1.1.12 Connection mode:wired, 2.4G, Bluetooth 3.0, Bluetooth 5.0

1.1.13 Compatible system Windows2000 or above,MAC,BLE support Windows 8 or above

65% Hot-Swap keyboard